


ZD220 Job Aid

Set paper size:

1. Click Start > Settings > Devices > Printers & Scanners > click the Zebra printer > click Manage > see screenshots below
2. The paper size is 2.375 W x 1 H



Calibrate Paper

1. Hold the feed button (above where it says ZD220 and to the right of the status light) until it flashes twice (about 6 seconds).

Status Lights

1. The status light is flashing green
 - a. This means the printer lost power
 - b. Press the feed button (next to the status) light once
 - c. The light should turn solid green
2. The status light is flashing red
 - a. This means the printer has detected the paper size is incorrect or the printer needs to be recalibrated
 - b. Follow set paper size and calibrate paper above.
3. The status light is solid green but the printer will not print
 - a. It is likely there is a communication issue between your PC and the Zebra printer
 - b. Restart your PC and try printing again
4. Print preview shows images bleeding off the label edges.
 - a. Follow set paper size and calibrate paper above.
5. Please make sure you are using Google Chrome.
 - a. If you do not have Google Chrome you can download it here:
www.google.com/chrome/